

Set Includes:

- Rear center diffuser
- 8x bolt M6
- 8x washer M6
- 8x nut M6
- Installation manual



1. Check fitting:

Line up splitter's edge with bumper edges. Check if the rear splitter is in the middle of the bumper.

1.



2. Install spoiler:

After fitting splitter, drill holes through bumper and rear center splitter.

2.



3. Insert nuts into drilled holes, add washers and tighten the nuts.

3.

